

# INSTALLATION INSTRUCTIONS



## Drop-In Bathtub

LUXART®

Alta Bella®

Thank you for selecting our products, which have been the benchmarks of fine quality for years. To help ensure that the installation process will proceed smoothly, please read these instructions carefully before you begin. Also, review the recommended tools and materials list; carefully unpack and examine your new plumbing fixture. Be sure to observe all plumbing and building codes according to your state requirements.

**CAUTION: PRODUCT IS FRAGILE. TO AVOID BREAKAGE AND POSSIBLE INJURY, HANDLE WITH CARE!**



### THE FOLLOWING ARE GENERAL INSTRUCTIONS FOR INSTALLING A DROP-IN BATHTUB. IT IS RECOMMENDED THAT A LICENSED PLUMBER INSTALL THIS PRODUCT.

- Observe all local plumbing and building codes.
- Confirm the correct model was received and measure the dimensions of the actual bathtub.
- The drop-in bathtub must only be supported by the feet or base. Do not support the bathtub by the rim.
- Check that the subfloor is level. Ensure the subfloor can adequately support the load of the bathtub filled with water.
- Before installing a rim-mount bathtub faucet, refer to the online product specification sheet. Ensure clearance under the rim and drain access from below before drilling faucet holes in the rim.

### CARE & MAINTENANCE

For best results:











- Always test your cleaning solution on an inconspicuous area before applying to the entire surface.
- Wipe surfaces clean and rinse completely with water immediately after applying cleaner. Do not allow cleaner to soak.
- Use a soft, dampened sponge or cloth. Never use an abrasive material such as a brush or scouring pad to clean surfaces.
- Rinse thoroughly and use a soft cloth to wipe the product dry after each use.
- Matte surfaces: NOTE: PLEASE BE CAREFUL WITH ALL PRODUCTS CONTAINING ABRASIVES. In order to maintain the aesthetics of a product it is recommended to use skin care oil once per month.

# INSTALLATION INSTRUCTIONS

## Drop-In Bathtub

LUXART®

Alta Bella®

<p>1. Construct the framing. Refer to the specification sheet.</p> 	<p>2. Optional Add-On Apron: Refer to the apron instructions and provide necessary support.</p> 	<p>3. Install the rough plumbing.</p> 
<p>4. Install the drain to the bath.</p> 	<p>5. For adhesive installation, apply a generous amount of construction adhesive to the bath feet or base.</p> 	<p>7. With help, lift the bath into position. Verify level. Ensure the feet or base are fully supported.</p> 
<p>8. Make the drain connections. Position a protective liner in the bath basin.</p> 	<p>9. Install water-resistant wallboard.</p> 	<p>10. Install the finished wall and deck material to within 1/16" (2 mm) of the bath rim.</p> 
<p>11. Apply 100% silicone sealant around the bath along the finished walls and deck.</p>  <p style="text-align: center;">Silicone Sealant</p>		



Luxart products manufactured by Interquatic® will be covered by Interquatic®'s warranty as follows:

**INTERQUATIC 10 YEAR LIMITED WARRANTY**  
**For Interquatic® acrylic freestanding and drop in bathtubs**

Interquatic®, warrants to the original consumer purchaser that it will, at its option, repair, replace, or make appropriate adjustments of the tub or any of its parts that are found by Interquatic®, in its sole judgment, to be defective under normal residential use and maintenance, so long as it is owned by the original consumer purchaser.

This limited warranty does not cover commercial installations or installations outside the continental United States.

This limited warranty DOES NOT COVER the following:

- Defects or damages arising due to shipping, installation, alterations, accidents, abuse, misuse, use other than bathing purposes, lack of proper maintenance and cleaning and use of other than genuine Interquatic® replacement parts, in all cases whether caused by a service company, plumbing contractor, the owner, or any other person.
- Deterioration through normal wear and tear and the expense of normal maintenance.
- Any modifications, alterations, or customization made by a service representative not authorized by Interquatic® will void warranty.
- Commercial Applications
- Options and accessories, including, aprons, drains, drain covers, overflow drain covers.
- Postage or shipping costs for returning products for repairs, replacement components or replacement unit under this limited warranty.
- Labor or other costs incurred in connection with product removal and/or installation under this limited warranty.
- ANY LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, ALL OF WHICH ARE HEREBY EXPRESSLY DISCLAIMED, OR THE EXTENSION BEYOND THE DURATION OF THIS LIMITED WARRANTY OF ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY OF FITNESS FOR AN INTENDED PURPOSE. IN NO EVENT SHALL THE LIABILITY OF INTERQUATIC® EXCEED THE PURCHASE PRICE OF THE PRODUCT OR ACCESSORY. (Some jurisdictions do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so these limitations and exclusions may not apply to you.)
- Responsibility for compliance with local code requirements. (Since local code requirements vary greatly. Distributors, retailers, dealers, installation contractors, and users of plumbing products should determine whether there are any code restrictions on the installation or use of a specific product





This warranty gives the original consumer purchaser specific legal rights. You may also have additional rights which vary from state to state, in which case this limited warranty does not affect such statutory rights.

All written or implied warranties are limited to the durations expressed here within. All units must be water tested before installation to validate warranty.

**Accessories not factory installed are not covered under this warranty.**

**Covered Products:**

Acrylic free-standing bathtubs  
Acrylic drop-in bathtubs

**Warranty Service:**

In order to make a claim under this warranty, the original consumer purchaser must notify Interquatic® in writing no later than fifteen (15) days from occurrence and must be within the expressed warranty period(s). Send a description of the product, model, and defect to the following address:

**Interquatic®  
Warranty Service Department  
15565 Wright Brothers Dr.  
Addison, TX 75001  
(214) 572-2000**

With the issuance of this warranty, Interquatic® stipulates, and the purchasers agrees, that in the event litigation is instituted as a result of this limited warranty, said litigation will be controlled by the applicable laws of the State of Texas, and the buyer and seller both agree that the appropriate forum and venue for any such litigation will be in Dallas County, State of Texas.

*\*Effective July 1, 2023, due to an update in California law, the start date for product warranties will now be aligned with the date of delivery of the product. This change is for all Luxart products purchased on or after July 1, 2023 by California consumers. (California Legislative Information AB-2912)*

