

PRESSURE GAUGES



LAZY HAND WATER TEST GAUGE

3/4" FHT brass swivel connection

Regular pressure hand (shown at zero pushes LAZY hand (shown at 240 lbs.) to peak operating or surge pressure point where it remains until you manually reset it.

Excellent to determine if P/T valve is leaking from failure or if leaking is caused by surge or excessive pressures (gauge attached to boiler drain overnight)
LAZY hand operates over entire gauge range.



PART NUMBER	PSI
1423	0-160#
1428	0-300#

AIR TEST GAUGE ASSEMBLIES

All parts precision made and assembled with sealant

3/4" FPT
2" Gauge
* Ashcroft



PART NUMBER	PSI	INCREMENTS
1427	0-30 #	1/2#
1427-A*		
1420	0-60#	1#
1420-A*		
1421	0-100#	2#
1421-A*		

AIR TEST GAUGE ASSEMBLIES



Photo shown is top mount

3/4" or 1" FPT
All parts precision made and assembled with sealant
2" Gauge
Bell reducer type
* Add -B for bottom mount

PART NUMBER	PSI	FPT SIZE
1410	1/10-15#	3/4"
1411*	0-30#	
1412*	0-60#	
1413	0-100#	
1414	0-30#	1"
1415	0-60#	
1416	0-100#	
1419	1/10-15#	

WATER TEST GAUGE ASSEMBLIES

3/4" FHT brass swivel connection

PART NUMBER	PSI	GAUGE SIZE
1431	0-160 #	2"
1432	0-300 #	
1440	0-160 #	2-1/2"
1430	0-300 #	



CONNECTION ONLY

PART NUMBER	DESCRIPTION
1402	3/4" FHT X 1/4" FPT Swivel connection

1/10 PSI AIR TEST GAUGE ASSEMBLY

15 # gauge scaled in 1/10# increments
Complies with Section 319.0 of Uniform Plumbing Code
All parts precision made and assembled with sealant
3/4" FPT
2" Gauge



PART NUMBER	PSI	INCREMENTS
1726-10G	0-15#	1/10#

SEPARATE AIR TEST GAUGE COMPONENTS

PART NUMBER	DESCRIPTION
1404	Air test gauge body ONLY
1405	Air test gauge body with air valve
1406	1/8" Air valve with cap ONLY
1417	3/4" Bell reducer with air valve
1418	1" Bell reducer with air valve

For individual pressure gauges see the next page